

ORA

LOUNGE ARMCHAIR



ORA LOUNGE ARMCHAIR

Designer	George Tsironas
Dimensions	W72 x D82 x H79 - SH44 cm
Materials	Powder coated aluminum frame Seat and back in textylene Seat and back cushions upholstered in fabric or eco leather
Weight	8.1 kg
Volume	0.47 m³



Sustainability

10DEKA prioritizes its ecological footprint by using recyclable materials and manufacturing practices to minimize the waste and the energy consumption, while continuously expanding the range of eco-friendly products. Our stringent adherence to global standards ensures that our products meet rigorous criteria for strength, durability, and safety.

Warranty

10DEKA offers a 2-year warranty on its products, valid ONLY with proper use. It excludes faults from normal wear and tear. If a manufacturing defect is found, the company will decide to repair or replace the product. For more information, please reach out to our sales team.



ORA LOUNGE ARMCHAIR

Fabrics































			
F11 Coco 8001	F12 Grafito 8013	F13 Lino 8008	F14 Marfin 3741
			
F16 Perla 3735	F19 Brisa Blue 3736	F20 Brisa Grey 3730	F28 Brisa 8011
			
F29 Optic 3934	F32 Aqua 8006	F39 Mineral 1442	F92 Umbra 20203
			
F93 Nectar 20200	F94 Scarlet 3947	F95 Apio 20201	F96 Gris Porcelana 20099
			
F97 Salvia 20081	F98 Fossil 3659	F99 Alga 3667	F100 Stone Grey 3669
			
F127 Ash Grey PVC	F128 Greige PVC	F26 Clara 3950	F76 Mostaza 1732
			
F77 Integral 1734	F78 Piedra 1730	F84 Avera 1712	F85 Gris 1714
			
F87 Stone 1709	F88 Brisa 1706	F101 Musgo 1701	F102 Mostaza 1713
			
F103 Ice 20234	F104 Albero 20238	F105 Fresh 20239	F106 Copper 20240
			
F107 Denim 20242	F113 Terra Stripes 00	F114 Sand Stripes 96	F115 Denim Stripes 98
			
F116 Terra Pinstripes 18	F117 Sand Pinstripes 14	F118 Denim Pinstripes 16	

Maintenance

















Regularly vacuum your furniture using the upholstery nozzle to remove dust and prevent fluff and pilling. Occasionally, straighten the fabric with your hands. To smooth out wrinkles, use a steamer. If liquids spill, immediately blot the area with an absorbent napkin or cloth, dabbing gently towards the center of the stain. Avoid using concentrated detergents, bleach, ammonia, optical brighteners, or soaps meant for hard surfaces. Spot cleaning is not recommended as it can damage the fabric and cause color loss. For wool fabrics, most stains can be removed with lukewarm water and a clean, lint-free cloth. If needed, add a small amount of neutral detergent. Do not rub the material vigorously, as this can cause color loss and fabric damage. Using a hairdryer may help to prevent water marks. If a stain persists, consult a professional cleaner.

ORA LOUNGE ARMCHAIR

Fabrics

			
F89 Gris 1742	F90 Glacier 1740	F91 Grafito 1739	F111 Ottoman Apio 20069
			
F112 Ottoman Umbra 20071	F119 Sky 01	F120 Sky 22	F121 Sky 03
			
F122 Sky 07	F123 Sky 11	F124 Sky 23	F125 Sky 20
			
F126 Sky 21	F108 Papyrus 20246	F109 Grey Sand 20247	F110 Optik 20245
			
CLI B123 Obvious Cliff	CLI B126 Slate Cliff	CLI B128 Jacket Cliff	CLI B129 Petra Cliff
			
CLI B131 Fir Cliff	LOP2 R079 Bud Lopi	LOP2 R081 Fawn Lopi	LOP2 R082 Pepper Lopi
			
LOP2 R085 Viper Lopi	LOP2 R086 Fossil Lopi	SLO 19011 Farafra Slow	SLO 19103 Alezan Slow
			
SLO 19106 Fern Slow	SLO 19107 Spirea Slow		

Eco Leather






















			
L1 Beige	L2 Beige Olive	L3 Ivory	L4 White
			
L5 Blue	L6 Graphite	L7 Light Grey	L21 Ebony
			
L22 Ash	L23 Ice	L24 Ocean	L25 Pearl
			
L26 Shark	L27 Terracotta	L28 Toffee	L29 Walnut

ORA LOUNGE ARMCHAIR

Frame Colors

			
White	Sabbia	Beige	Dark Brown
			
Light Grey	Cloud Grey	Graphite	Turquoise Blue
			
Royal Blue	Denim Blue	Olive Green	Saumon Orange
			
Rouge Beige	Rouge Royal	Tanami Red	Brown Amber

Textylene

			
T1 Tramato Beige	T2 White	T3 Tramato Grey	T5 Mocca Brown
			
T7 Graphite	T8 Solid Beige	T9 Light Grey	T10 Denim Blue
			
T11 Cloud Grey	T12 Latte Brown	T13 Apricot	T14 Red Rose
			
T15 Ocean Teal	T21 Sugar White	T22 Gold Cane	T23 Terra Stripes
			
T24 Cherry Stripes	T25 Grey Chess	T26 Olive Mesh	T27 Terracotta Clay
			
T28 Desert Sand			